

YAESU FT-7900R/E

(BOLD) = hold for 1 sec; CAPS = tap quickly)

Set Power Level: LOW(ACC), repeat to desired level

Change Bands: BAND(SET, repeat to desired band

Scan: SCAN(SEL), SCAN(SEL) or PTT to stop scan
Turning dial one click either way reverses direction of scan.

Set CTCSS Tone: TONE(HM/REV) repeat to "ENC"
BAND(SET), then DIAL to "TN FRQ" (44)
BAND(SET), then DIAL tone frequency
BAND(SET), **BAND(SET)**

Tone Off: TONE(HM/REV), repeat to "OFF"
BAND(SET): BAND(SET)

Disable Repeater Offset: IN VFO BAND(SET)
DIAL to "RPT.MOD" (33), then BAND(SET),
DIAL to "OFF" then BAND(SET), then **BAND(SET)**
Rotating the dial on click will revert to normal offset

Reverse Repeater input and output: TONE(REV) , repeat to undo

Memory Store: Select frequency (and CCTSS Tone)
V/M(MW), DIAL memory channel if different than next available
V/M(MW) to save or **V/M(MW)** to name
DIAL first character of name, BAND(SET)
Repeat previous line up to 6 characters
(Mic DWN to move back a space)
BAND(SET)

Memory Recall: V/M(MW) to toggle between Memory and VFO

See Memory Channel Frequency: Mic B

Delete Memory Channel: In memory mode, **V/M(MW)**
DIAL channel to be deleted, SCAN(SEL)

Weather Channel: **LOW/ACC** toggles between Weather Channels and VFO